



Installing stageVIEW™

Follow the below instructions for installing stageVIEW™ software used for ATS automatic temperature and velocity scanners, including the ATVS-2020™, eATVS-4™ & eATVS-8™.



Step 1

Access Advanced Thermal Solutions' FTP website:

» <ftp://atsins@atsftp.homeftp.net/>

Enter Username:

» ATSENS

Enter Password:

» caliber

Step 2

Open the ATS-Instrumentation folder.

Step 3

If you are installing stageVIEW™ for the first time, or upgrading your version, including drivers:

» Download the complete stageVIEW™ 2.88 directory.

If you need calibration only, and are running the current version of stageVIEW™:

» Download the file "ATVS-2020 Calibration Data" under the calibration directory.

Then click the "Load cal file" button on stageVIEW™ to refresh your calibration file.

For assistance with installation, updates and calibration, please contact Advanced Thermal Solutions, Inc. by phone: 781.769.2800 or email: ats-hq@qats.com