

Accurate Temperature Measurement

How It Impacts Reliability Calculations and Product Launches




Figure 1. The Role of Thermal Management and Analysis in a Typical Product Design Cycle.

Power dissipation from electronics is on the rise, and so is its consequence on temperature. As a result, accurate temperature measurement is playing a larger role in the successful launch of new products.

Figure 1 shows a typical flow chart for a product's design cycle [1]. Thermal engineering is required in three distinct stages: Concept, Prototype, and Verification.

At the Concept level, thermal analysis is performed to

ascertain the design feasibility and move the product to the Prototype stage. Here, the product is assembled and temperature measurements are taken to ensure the design meets the intended specs while there is a level of system functionality. If the design passes this stage, the product is fabricated. Then, the fully-functional system is checked for adherence to its intended design features while it is stressed at elevated temperatures. This is part of the Verification stage.

THERMAL ANALYSIS

At all three stages, accurate knowledge of temperature is needed to ensure the system meets expected performance levels. An engineer designing an MRI system certainly wouldn't want to include non-existing, extra features in the digital image as a result of excess temperature. Nor, by analogy, would someone transferring funds in a bank transaction want their electronics to place extra zeros in the transfer amount because of temperature overshoots in the system.

Equally important is the expected life of an electronics system. Every company wants to ensure that its products will successfully function in their intended environment. And every company wants their products to be first on the market. To support these goals, a fair amount of reliability calculations must be performed.

To fully appreciate the role of temperature in reliability calculations, and how important it is to accurately measure or estimate temperature, consider the following equations. Arrhenius and Eyring models are commonly used in reliability calculations, as shown in Equations 1 and 2, respectively [2].

$$k = k_o e^{-\frac{E_a}{k_B T}} \quad (1)$$

And

$$k = k'_o T^n e^{-\frac{E_a}{k_B T}} \quad (2)$$

The temperature acceleration factor is given by Equation 3:

$$A_T = e^{\frac{E_a}{k_b} \left[\frac{1}{T_1} - \frac{1}{T_2} \right]} \quad (3)$$

Where:

A_T = temperature acceleration factor

E_a = activation energy

k = reaction rate

k_o and k'_o = pre-exponential factor

k_b = Boltzmann constant

n = relates to reaction dynamics (0.7)

T = temperature (K)

Experts in the field of reliability argue about the accuracy and consistency of these models. Nevertheless, they are used extensively for reliability predictions.

More importantly, in all these equations temperature plays a pivotal role in the magnitude of the expected life. Temperature directly impacts an engineer's decision on the cooling system selection, launch, or redesign of a product.

Temperature has a direct role in the fail-proof operation of electronic components, and subsequently the complete system. Thermally induced stresses will create failures in the system if they are not managed. Device and fluid temperature directly impact the magnitude of such stresses. This is best demonstrated by Equation 4, describing the stress in the lead-wire.

$$\sigma = \frac{\lambda E \Delta \varphi T}{2L_e} \left(\frac{\pi r}{R_A} \right)^{0.5} \quad (4)$$

Where:

E = modulus of elasticity

L_e = wire-bond characteristic length

k_b = Boltzmann constant

R_A = aspect ratio of the deformed section

r = undeformed wire radius

T = temperature

s = stress at the wire-bond attachment

λ = stress concentration

Zero Downtime 2007
Advanced Technology for Protecting Mission
Critical Electronic Equipment

Zero Downtime is the only conference focused on the latest advancements in protecting electronic equipment for data centers, communication and control networks, 24X7 industrial and facility systems, infrastructure and other mission-critical electronic systems.

*Featuring a pre-conference workshop by
Advanced Thermal Solutions, Inc.
Electronics Cooling: Challenges and Solutions
November 5th - 9:00am - 1:00 pm*

*Challenges and Solutions is presented
by ATS' President & CEO Kaveh Azar Ph.D.,
an internationally recognized expert in the
thermal management of electronics.*

www.EquipmentProtectionMagazine.com

November 5-7, 2007 - Scottsdale, AZ.

THERMAL ANALYSIS

Equation 4 shows a linear relationship between stress and temperature. Any mis-prediction of temperature will result in the under- or over-prediction of stresses that factor into an engineer's decision making process.

Let's bring this issue to the device level. Consider the following devices:

1. A stand-alone device, i.e., a single device residing on a board. This is typically what is arranged to perform device level characterization.
2. A system in-situ device, i.e., a device that resides in a system on a PCB, is surrounded by other components, and the board has signal traffic going through it.

To effectively characterize these components we need

to know the following temperatures:

- Case
- Junction
- Approach fluid (e.g., the air temperature measured at half device length, upstream, at the channel center formed by two PCBs).

In the first situation, stand-alone device, while the heat transfer is highly three dimensional, the boundary condition for the device is very clear and easily quantified. In the in-situ example, the thermal boundary condition for the device is rather complex. The heat transport dynamics can be affected by the functionality and the traffic on the PCBs in the system. Therefore, the error in measurement can be very expansive when you compare these two cases. Table 1 shows the magnitude of such errors based on field observations.

Table 1.
Errors in Temperature Calculation and Measurement for Component Characterization for Stand-alone and In-Situ Devices.

Device Location	Temperature Variation	Uncertainty in Calculation	Uncertainty in Measurement
Stand - Alone Device			
Case	20 °C	8 - 15%	5 - 10%
Junction	30 °C	15 - 25%	5 - 10%
Approach fluid	2 °C	2 - 4%	2 - 5%
Cumulative Uncertainty		17 - 29%	7 - 15%
In - Situ Device			
Case	20 °C	15 - 30%	5 - 10%
Junction	30 °C	20 - 50%	3 - 7%
Approach fluid	2 - 30 °C	5 - 15%	4 - 50%
Cumulative Uncertainty		25 - 63%	7 - 51%



Interested in placing an ad in Qpedia? Contact Ray Santos at rsantos@qats.com for information and pricing.



THERMAL ANALYSIS

The Temperature Variation column in Table 1 shows typical data seen in the field during device characterization. In both stand-alone and in-situ conditions, device case temperature measurement is very much a function of location on the case. The variations can range from a couple of degrees to several tens of degrees depending on device packaging and power dissipation. The same applies to the junction temperature measurement.

The reason for these wide temperature ranges stems from the structure of the die. The die is a miniature PCB with significant heat flux variations running across it. It is often very difficult to ascertain the location of the hottest point, i.e., the junction. Therefore, variations of 30°C or higher are readily seen.

The other common error when performing temperature characterization and measurement is found with the approach fluid temperature. In the case of a stand-alone device, because the work is typically done in a wind tunnel, the approach air temperature is impacted by the free ambient. Thus, 2°C is a reasonable variation. However, with the in-situ device, since the component resides on a PCB, the air temperature variations are rather large, depending on the upstream power dissipation, and on component layout and geometry. Because of the board layout, one can often see 20°C air temperature variations in an area less than 5 cm².

The third and fourth columns in Table 1 are typical uncertainties observed in temperature calculation and measurement of the aforementioned parameters. As shown, this uncertainty is especially high when we focus on in-situ measurement with respect to approach fluid (air temperature and velocity). Considering the complex environment of a PCB, this variation clearly results from the geometry, power, heat flux density, and the tool type used for calculation and measurement.

As Table 1 shows, cumulative uncertainties for in-situ and stand-alone conditions can create a rather large variation in the resultant temperature. Let's look at an example.

Referring back to Equation 3, the temperature acceleration factor often used in reliability calculations, consider the following:

$$\begin{aligned} T_1 &= 40^\circ\text{C} \\ T_2 &= 150^\circ\text{C} \\ E_a &= 0.4 \text{ eV} \\ k_B &= 8.6 \times 10^{-5} \text{ eV/K} \end{aligned}$$

This results in a temperature acceleration factor (A_T)

of 48 for the normal, non-error condition. Now, based on Table 1 we will impose 10% and 35% uncertainties in the temperature measurement of T_2 . Table 2 below shows the results of these errors on the acceleration factor.

Table 2. Effects of Uncertainty in Temperature Measurement on Acceleration Factor (A_T).

Uncertainty	Temperature (°C)	Acceleration Factor (A_T)	% Error
0%	150°	48.0	0%
10%	165°	69.4	43.7%
35%	202°	158.6	230.0%

Despite the fact that the 10% and 35% errors in this example are significantly lower than the extremes shown in Table 1, the resulting temperature and the value of A_T are rather daunting.

Taking this to the next level, an engineer may need to make a decision based on the numbers generated in Table 2 – without realizing the potential errors in temperature determination, i.e., quick calculations or measurements.

Let us define η as a factor of goodness in the design defined by Equation 5.

$$\eta = (T_2 - T_a) / (T_{2,\text{spec}} - T_a) \leq 0.9 \text{ or } 90\% \quad (5)$$

Where:

T_2 = the reference temperature (e.g., junction or case)

T_a = the approach air temperature to the device

$T_{2,\text{spec}}$ = the device-specific temperature provided by the manufacturer. (Beyond this temperature the device will fail.)

Equation 5 implies that once the design is complete, at least a 10% margin should be allowed to ensure its safe function, as not all thermal contributions to the device can be accurately quantified. If we calculate the η value for these cases, and if the $T_{2,\text{spec}} = 155^\circ\text{C}$ and the $T_a = 55^\circ\text{C}$, we see the results in Table 3 for η .

THERMAL ANALYSIS

Table 3. Impact on Design Quality as the Result of Uncertainty in Measurement or Calculation.

Uncertainty	Measured or Calculated T_2	η	Target η	Δ
0%	150°C	0.95	0.9	5%
10%	165°C	1.1	0.9	20%
35%	202°C	1.47	0.9	58%

If there were no errors, the T_2 calculation shows that the design is not satisfactory, but the margin of 5% is small enough that, with minimal additional effort, it can be remedied. The 10% and 35% uncertainties create results that are off target by 20-58%. If they were not the manifestation of bad engineering practices, they would require significant effort to fix. Conversely, they may force the engineer to consider a higher capacity cooling system with little-to-no market appeal and significantly larger cost – or alternatively recommend a total redesign of the system!

It is thus shown that uncertainty and error in measurement or calculation (including numerical simulation, e.g., CFD) may lead to decisions with product-stopping consequences. In the case of temperature, a significantly more costly cooling solution may be considered. In the case of reliability calculations, more costly components may be specified so the product will meet the expected life. And this is all because of poor measurement practices, or inappropriate sensors or analysis tools. If being first-to-market with reliable and functional products is important, it is prudent to understand the tools we use for our analyses (measurement or simulations) and consider the uncertainties associated with such tools before making a decision.

References:

1. Azar, K., Reliability Analysis and Uncertainty in Temperature Prediction, Thermic Conference, 2002.
2. Klinger, D., Nakada, Y., and Menendez, M., AT&T Reliability Manual, Van Nostrand Reinhold, 1990.



ATS ADVANCED
THERMAL
SOLUTIONS, INC.
Innovations in Thermal Management®



OVERALL DIMENSIONS (L X W X H)
91 cm X 44 cm X 44 cm
(36 X 17.25 X 17.25")

TEST SECTION DIMENSIONS
50.8 cm X 44 cm X 10 cm
(20 X 17.25 X 4")

MATERIALS
ALUMINUM, PLEXIGLAS

FLOW RANGE
0 TO 6 M/S (1200 FT/MIN)

WEIGHT
14.5 kg (32 lbs.)

INTRODUCING THE BWT-104 Benchtop Wind Tunnel

The BWT-104™ is a research quality, open loop, benchtop wind tunnel for thermal characterization of components, circuit boards and cooling devices such as heat sinks, heat exchangers and cold plates. It provides homogeneous flow, up to 6 m/s (1200 ft/min) within its Plexiglas® test section, has 12 ports for probes and sensors, and can be operated on any axis, making it ideal for laboratory environments.

For further technical information, please contact Advanced Thermal Solutions, Inc. at **1-781-769-2800** or www.qats.com